



Corner Cable Shelf

Note:

Although basic mounting hardware is included, be sure to use the proper mounting hardware for your wall type. When in doubt consult your local hardware store.




Parts Included:

- 1 Corner cable bracket
- 1 Corner washer
- 1 Mounting screw
- 1 Glass shelf
- 2 Corner bumpers



Mounting Instructions:

1. Pre-assemble shelf within back channel and hold mounting bracket to wall to determine desired location. With a pencil, mark the location of the screw hole. Remove from wall.
2. Using corner washer, mount bracket to wall corner with screw provided or proper hardware for your wall type (fig. 1). *Note:* In some instances, a toggle bolt may be needed to mount bracket into corner.
3. Put the back flat edge of glass shelf into the back channel on cable (fig. 2).
4. Bring cable around front of shelf. Put cap fitting onto wall fitting (fig. 3). *Note:* keep cables uncrossed.
5. Put channels onto front outermost edges of glass (fig. 3).
6. Gently push shelf down into place, leveling by pulling cable from below (fig. 4). *Note:* Back double cable will form a natural twist. If desired, they can be untwisted at top.
7. Check gap between shelf edges and wall. If necessary, apply rubber bumpers to edge of glass (fig. 5).



Care Instructions:

Wipe with a soft, dry cloth.

thank you for your purchase

NOTE: DISTANCE FROM CENTER OF
SCREW TO BOTTOM OF SHELF
10"X10"= 12"
12"X12"= 10"

Questions or comments call Expo Design Inc. (516) 674-1420
www.expodesigninc.com